

Filter Technology - Intake Pit Filter

Inspection hole for cage type HR

Description

Intake pit filters with cage type HR are equipped with an inspection hole, located in the clean air chamber above the inspection door.

The inspection hole provides access to the clean air chamber for installation of the last bag/cage as well as for removal of the first cage.

Instructions for installation and removal of bags and cages are found on separate pages.



Fig. 1. The cover for the inspection hole is secured with 4 pcs. M8 screws. Loosen the screws with a spanner and remove the cover.



Fig. 2. The inspection hole is used when installing the last bag/cage and when removing the first cage. The bag installation should be planned so that the last bag/cage is installed within reach of the inspection hole.



Fig. 3. Before re-securing the cover, make sure that the sealing is intact. If not, it should be replaced.